

### CBL-120-300-C00

**Cable for product :** Generic HSM – bar code scanner  
**Description:** RS232C +/-12V POD coiled DB9 fem. 5V PIN 9  
**Interface:** RS323C  
**Connector A:** Molded 10 Pin Modular (RJ50 like)  
**Connector B:** Molded DB9 – Female  
**Connector C:** STD HSM Power link 5V (DC Jack with shunt)


**Cable length:** 3.00 meter  
*Max extended*

#### Pin assignment


Color	Device End		Converter POD In		Converter POD Out	External Power Pod		Host End	
	Pin	Signal	PIN	Signal	Signal	PIN	Signal	Signal	Pin
Yellow	1	Drain	1	Drain	Drain	8		Drain	SH
Green	2	Ground	7	I/F DETECT	DSR_Optional	3	No Connect		
Black	3	Ground	3	GND	GND	1	DC Jack Center Pin	Ground	5
White	4	TXD (Device Output)-TTL	4	TTL TXD	True TXD	7		TXD	2
Blue	5	RXD (Device Output)-TTL	5	TTL RXD	True RXD	5		RXD	3
Grey	6	CTS (Device Output)-TTL	6	TTL CTS	True CTS	6		CTS	7
Red	7	Device +5V	8	+5 Volt Power	+5 Volt Power	2	DC Jack Sleeve	DTR	6
							DC Jack Shunt	Host +5V	9
Orange	8	RTS (Device Output)-TTL	2	TTL RTS	True RTS	4		RTS	8
	9	No Connect							
	10	No Connect							
								No Connect	1
								No Connect	4

#### Connector assignment

**Connector A**



**Connector B**



**NOTE:**

Converts +/- 12V RS232C host signals to +5 V TTL level scanner signals through an included converter POD.

**WARNING:** connecting to 12V host powered systems with these cables will damage the 5V-only scanner when the External Power (PSU) is disconnected from con. C.

*Under no circumstances will Honeywell International Inc. be liable to any person or business entity for any direct, indirect, special, incidental, consequential or other damages based on any use of the information in this document or any other linked or referenced document, including, without limitation, any lost profits, business interruption, or loss of programs or information, even if Honeywell International Inc. has been specifically advised of the possibility of such damages.*