

# PC43d | PC43t

## Cutter Tray Instructions

切刀托盘说明

切紙盤說明

Instructions relatives au plateau du massicot

Anleitung für das Schneidvorrichtungsfach

Petunjuk untuk Baki Cutter

Istruzioni per l'uso del vassoio della taglierina


커터 트레이 안내서

Instruções para o uso da bandeja do cortador

Инструкции к лотку резака

Instrucciones de la bandeja del cortador

Kesme Tepsisi Talimatları



Use this tray only with the cutter accessory for the PC43d and PC43t printers.

仅型号为 PC43d 和 PC43t 的打印机的切刀配件可使用此托。

此紙匣僅適用於 PC43d 和 PC43t 印表機的切紙器配件。

Utilisez ce plateau uniquement avec le massicot des imprimantes PC43d et PC43t.

Diese Ablage ausschließlich mit dem Trennvorrichtungszubehör der Drucker PC43d und PC43t verwenden.

Gunakan baki ini hanya dengan aksesori cutter untuk printer PC43d dan PC43t.

Usare questo vassoio solo con la taglierina (accessorio) per le stampanti PC43d e PC43t.

PC43d 및 PC43t 프린터의 커터 부속품에는 이 트레이만 사용합니다.

Esta bandeja só deve ser usada com o acessório de corte para impressoras PC43d e PC43t.

Используйте этот лоток только со вспомогательным резаком для принтеров PC43d и PC43t.

Use esta bandeja únicamente con el accesorio cortador para impresoras PC43d y PC43t.

Bu tepsiyi yalnızca PC43d ve PC43t yazıcılara ait kesme aksesuarı ile kullanın.



Worldwide Headquarters  
6001 36th Avenue West  
Everett, Washington 98203  
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2011 Intermec Technologies  
Corporation. All rights reserved.



PC43d and PC43t Cutter Tray Instructions



P/N 943-321-001